

USB to I²C Bus Interface - Sample Project

Overview


This example project for the FT2232C demonstrates how to use the devices Multi-Protocol synchronous Serial Engine (MPSSE) to make a USB to I²C bus interface. The executable application and full project code (in Delphi) are provided.

Requirements

This project is designed to run on Windows 2000 or Windows XP and requires FTDI's FT2232C drivers to be installed


Test Circuit

This project was developed and tested using the following circuit. 4 of the signal lines on channel A of the FT2232C were used.



Running the Sample Application

Run I²CTest.exe. The following dialogue window will be shown. Use the Device name drop down menu to select the MPSSE device that you want to talk to.



Read - this will read the current contents of the 24LC02. If the EEPROM is blank FF's will be shown.

Erase - this will erase the EEPROM contents.

Prog To Addr - This will program the address value (in hex) to each address in the EEPROM. i.e. 0000 will be programmed to address 0000, 0001 to address 0001,...., and 007F to address 007F.

Prog Frm File - This allows the EEPROM to be programmed with data from a file stored on the PC. The file used to program can be selected using Open from the File menu. The file path will be displayed under the File Name field.

I2C Address - Can be used to select the target device using the address lines if multiple I²C devices are connected to the FT2232C.

Clk Divisor - Allows the clock divisor for programming the EEPROM to be set.

The full Delphi project files are available for this application program.

Further Information

FT2232C Device Datasheet

AN2232C-01 - Command Processor For MPSSE and MCU Host Bus Emulation

AN2232C-02 - Bit Mode Functions for the FT2232C

FT2232C-Proj01 - USB to SPI Bus Sample Project

Document Revision History

FT2232C-Proj02 Version 1.0 – Initial document created May 2004. FT2232C-Proj02 Version 1.1 – November 2004 - Circuit diagram updated.

Disclaimer

© Future Technology Devices International Limited, 2002 - 2004

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any

particular purpose is either made or implied.

Future Technology Devices International Ltd. will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected.

This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury.

This document provides preliminary information that may be subject to change without notice.

Contact Information

Future Technology Devices International Limited 373 Scotland Street, Glasgow G5 8QB, United Kingdom.

Tel: +44 (0)141 429 2777 Fax: +44 (0)141 429 2758

E-Mail (Sales) : sales1@ftdichip.com
E-Mail (Support) : support1@ftdichip.com

E-Mail (General Enquiries) : admin1@ftdichip.com

Web Site URL: http://www.ftdichip.com

Agents and Sales Representatives

Please visit the Sales Network page of the FTDI Web site for the contact details our distributor(s) in your country.